

Motorola UHF Mitrek direct modulator modification  
4/12/2009 S.Rodgers

Using picture below:

Remove R513, a 200 ohm 1/4W resistor on the main board

Remove the L16 wire jumper on the interconnect board

Install a Wire from the Pin 16 connector end of L16 to the end of R513 closest to the radio casing.

Connect external modulator input to pin 16 of external radio connector

